

<p><b>1</b> ALL COMPONENTS</p> <p>NB: BEFORE PLACING 2ND SIDE INTO PLACE, PLEASE ENSURE TO CENTRE THE MULLION FOR UNITS WITH 2 OR MORE DOORS</p>	<p><b>2</b> START WITH BOTTOM AND RIGHT SIDE</p> <p>INSERT THE CAM SCREW INTO THE SIDES SO THAT IT PROTRUDES ENOUGH FOR THE HEAD OF THE SCREW TO BE ROUGHLY CENTRED IN THE CAM WHOLE IN THE BASE</p> <p>START WITH THE TRIANGLE POINTING TO THE SIDE PIECE</p> <p>TURN A HALF ROTATION SO THAT THE TRIANGLE POINTS TO THE INSIDE OF THE CABINET</p>	
<p><b>4</b> SLIDE IN THE BACKING BOARD</p> <p>SLIDE THE BACKING BOARD INTO THE GROOVE</p>	<p><b>3</b> JOIN TOP PANELS AND CLEAT TO THE RIGHT SIDE</p>	
<p><b>5</b> FIX THE OTHER SIDE</p> <p>FIX THE REMAINING SIDE INTO PLACE</p>	<p><b>6</b> FLIP OVER AND ADD THE LEGS</p> <p>FLIP THE CABINET UPSIDE DOWN</p> <p>PLACE THE LEGS 16MM AWAY FROM THE EDGE OF THE UNIT WITH THE TAB FACING OUT AND SCREW DOWN</p>	<p><b>7</b> SECURE LEGS AND FLIP IT OVER AGAIN</p> <p>ADJUST THE HEIGHT OF THE LEGS AND FLIP IT RIGHT WAY UP AGAIN</p> <p>NOW YOUR CABINET IS FINISHED AND CAN BE ALIGNED WITH OTHERS TO CREATE A BIGGER CABINET A DOOR, SHELVES, COUNTER TOP CAN BE ADDED AS YOU NEED</p>