

<p><b>1</b> ALL COMPONENTS</p>	<p><b>2</b> ADD THE TOP AND BOTTOM RAILS TO THE RIGHT SIDE</p> <p>START ASSEMBLY ON A FLAT SURFACE SUCH AS THE FLOOR</p> <p>INSERT THE CAMS IN THE PRE-DRILLED HOLES</p> <p>THE CAMS FOR THE BOTTOM SHELF IS TIGHTENED FROM BENEATH.</p> <p>APPLY A LITTLE COLD GLUE INTO THE DOWEL HOLES BEFORE ASSEMBLY</p> <p>BRING TOGETHER AND TIGHTEN THE CAMS</p>	<p><b>3</b> ADD THE BAKING BOARD</p> <p>SLIDE THE BACKING BOARD INTO THE GROOVE</p>
<p><b>USING THE CAM SYSTEM</b></p> <p>INSERT THE CAM SCREWS INTO THE SIDES SO THAT IT PROTRUDES ENOUGH FOR THE HEAD OF THE SCREW TO BE ROUGHLY CENTRED IN THE CAM HOLES IN THE BASE</p> <p>START WITH THE TRIANGLE POINTING TO THE SIDE PIECE</p> <p>TURN A HALF ROTATION SO THAT THE TRIANGLE POINTS TO THE INSIDE OF THE CABINET</p>	<p><b>4</b> ADD THE LEFT SIDE</p> <p>FIX THE REMAINING SIDE INTO PLACE</p>	<p><b>5</b> ADD THE LEGS AND ADJUSTABLE SHELVES</p> <p>TO INSERT THE FEET THE CABINET IS BEST PLACED ON THE FLOOR. PLACE THE LEGS 16MM AWAY FROM THE EDGE OF THE UNIT WITH THE TABS FACING OUT AND SCREW DOWN. TURN THE CABINET UPRIGHT AGAIN. SLIDE IN THE ADJUSTABLE SHELVES</p>